

Model 112 TaskMaster



www.eidosergonomics.com

Assembly Instructions

Tools Needed: (2) 9/16"wrenches, 3/4" socket, 1/2" socket & pliers.

Please read all instructions before assembling

Step 1: Loosen front caster hardware with a ½" socket and install A) Front caster by aligning and then tightening four pieces of hardware.

Step 2: Attach the (C) Back Rest Assembly to the frame using the enclosed ½-13 x 1 ¼ hex head bolts. Tighten using a 3/4" wrench.





Step 4: From the back of base, slide Release Mechanism, (left to right) through channel aligning center threads with center of channel.

Step 5: Turning clockwise, screw gas spring into release mechanism turning 12 full rotations. Tighten spring spacer with pilers.

Step 6: Put top of gas spring eyelet into bracket at the top of the back, slide 3/8-16 x 1 ½ bolt through the bracket, tighten with 3/8-16 reversible lock nut using two 9/16" wrenches.



Note: Do not allow the gas spring to fully acuate, This will Cause Problems when bolting gas spring to back.





Warranty: Eidos products are covered by a limited warranty for a period of five years from date of purchase.

*Online Product Registration:

http://www.eidosergonomics.com/product-registration.html





Eidos Corporation

4755 N. 48th Street, Lincoln, NE 68504 Telephone: 402-466-1119 FAX (402) 466-2023

E-mail: sales@eidosergonomics.com Web: www.eidosergonomics.com